



Battery Specifications | General Guidelines

Actall's ATLAS One Button and Two Button Round Tags use a CR2032 lithium battery; this can be provided by Actall or you can supply.



Changing the Battery on ATLAS One and Two Button Round Tags

To change the battery on the One Button and Two Button Round Tags, you must remove the cover to expose the compartment that houses the battery.

1



Step one:

To remove the battery cover, hold the front face of the tag in one hand and press down and twist the back of the tag counter clock wise.

Step two:



Remove the battery while taking care not to lose the rubber ring that creates a water resistant seal.



Step three:

Place new battery into the battery compartment.



Special Note: To ensure proper battery function, insert new battery text-side-up

4



Step four:

After replacing the battery, place the tag back in your hand, ensure you line the tag up with the gold colored programming strip to the left side of your hand and the back slightly to the left of the gold programming strip, push it down and twist clockwise to close the tag.



The information presented in this document are instructional illustrations of how to operate or maintain ATLAS System components. Image sizing is not to scale and are for informational purposes only. To learn more visit us online, send us an email, or give us a call.



Actall encourages behavior which supports a greener and safer planet and eco-friendly world. Products manufactured by Actall have electronic components and batteries, and should be disposed of in a manner that respects the environment.